

How to Set Phone Status to Do Not Disturb (DND) - Snom D785

When your phone is set to Do Not Disturb (DND), you will be able to make outgoing calls but your incoming calls will not ring and instead go directly to voicemail. Simply press the DND button (see Figure 1) to turn DND on and off. When DND is enabled, the status icon on your phone screen will change to red and state “DND” (see Figure 2).



Figure 1 – DND Button



Figure 2 – DND Status Symbol

Troubleshooting Tip

My phone isn't ringing for incoming calls, but I can make calls out.

If you can make outgoing calls on your phone but your incoming calls are going directly to your answering service solution, it is likely your phone is set to Do Not Disturb (DND). Usually this happens incidentally when the DND button is pushed by accident. Simply take your phone off DND by pressing the DND button to resolve this issue.